

# Current Monitoring Kit

## Important Note



### Instructions for Using the TA011 Current Clamp with the EnviroMon EL040 Current Monitor

Your TA011 Current Clamp has an **OUTPUT** switch on its front panel, as shown in the picture opposite.

You must set this switch to the "**1mV/A**" position, as shown, to allow the EL040 to measure the correct value of current.

#### For more information

Please refer to the setup and operating instructions in the *Current Monitoring Kit Quick Start Guide* supplied with your kit. If you do not have a copy of this guide, you can download one in PDF format from our website at:

[http://www.picotech.com/current\\_monitoring.html](http://www.picotech.com/current_monitoring.html)

#### Contacting Pico

Pico Technology  
James House  
Colmworth Business Park  
ST. NEOTS  
Cambridgeshire  
PE19 8YP  
United Kingdom

Tel: +44 (0)1480 396395  
Fax: +44 (0)1480 396296  
E-mail: [sales@picotech.com](mailto:sales@picotech.com)  
[support@picotech.com](mailto:support@picotech.com)  
Web: [www.picotech.com](http://www.picotech.com)

