

## Install command line options

<b>Quick Uninstall</b> .....	1
<b>Create an install log</b> .....	1
<b>Silent Installs</b> .....	1
<b>Package Codes</b> .....	<b>Error! Bookmark not defined.</b>
<b>Converter Codes</b> .....	<b>Error! Bookmark not defined.</b>

### Command Line Argument notes

Command line arguments are passed to the msi package via setup.exe using the /v switch. If Installing using the msi only, the /v switch is not require e.g.

```
setup.exe /v"/L picofull.log"
PicoInstall.msi /L picofull.log
```

### Quick Uninstall

To uninstall quickly, use the /x switch with the package code:

```
C:\WINDOWS\system32\msiexec.exe /x {45EEE30F-9E70-43E8-B263-50617FD085F5}
```

### Create an install log

To create an install log, us the /L switch. The log can be used to diagnose problems when the installer fails and rolls back.

```
setup.exe /v"/L picofull.log"
```

### Silent Installs

Silent installs can be used to install the software without user intervention, this is useful if installing on many machines. If an restart is required, the computer is rebooted automatically.

Progress bar only:

```
Setup.exe /v "/passive"
```

No UI

```
Setup.exe /v "/quiet"
```

To override the automatic reboot

```
Setup.exe /v "/norestart"
```

The PicoInstall.msi installer must specify a default converter. This is so PS /PL can be programmed with the correct default converter that at least one product is installed. To specify a converter set the DEFAULT\_CONVERTER property with a converter code. For example the ADC-100 can be installed as follows:

```
Setup.exe /v "DEFAULT_CONVERTER=100 /quiet"
```

To install all converters

```
Setup.exe /v "DEFAULT_CONVERTER=100 INSTALL_ALL_CONVERTERS="Yes"  
/quiet"
```

To change the default port change the DEFAULT\_COM\_PORT or the  
DEFAULT\_PAR\_PORT

```
Setup.exe /v "DEFAULT_CONVERTER=100 DEFAULT_PAR_PORT=2 /quiet"
```